
HWACHEON HRD-TEC

Hydraulic Rock Splitter
UP TO SIX SPLITTERS WORKING TOGETHER



Walter S. Pratt & Sons, Inc 317 Columbia St. Rensselaer, NY 12144 1-800-613-4738

RENTAL - SALES - SERVICE




※ Every holes distance different from rocks type.

% Make holes to be formed 15~30° angle against surfice.

Soft rock Normal rock : 24 - 32 Inches

Hard rock

: 16 - 24 Inches : 10 - 16 Inches



HRD ROCK SPLITTER

#516, Seoheung Techno Valley, 731-4, Wonsi-dong, Danwon-gu, Ansan-si, Gyeonggi-do, Korea

TEL.: +82-31-432-7832 FAX.: +82-31-497-7852

DO

- Wear safety glasses
- Wear safety gloves
- Wear Steel toe safety shoes
- Stay at least 20 feet away from hydraulic hoses when under pressure.
- Change hydraulic hoses and fittings if they are cut or leak with proper pressure spec hose and fitting and use extreme care not to allow any foreign material into the hose or fitting.
- Always face splitter pistons toward the free face of the excavation.
- Insert splitters fully into drilled holes.
- Use the proper electric power from the hydraulic pump motor to generator or electric source. (230 VT, Single Phase, 50 Amps)
- Check Hydraulic Oil level each day before starting to make sure it is full with the proper #32 hydraulic oil.


DO NOT

- DO NOT Keep the hydraulic pump in high pressure position after the rock has been broken. (You could take out the Pressure Pump.)
- DO NOT Keep the hydraulic pump in low pressure position after the pistons have been retracted back in the cylinder. You could take out the pressure pump.)
- **DO NOT** Touch the hydraulic hoses that are under pressure.
- **DO NOT** Raise the pressure on the hydraulic pump.
- **DO NOT** Place the electric hydraulic pump in or near water.
- DO NOT Lift or drag splitter cylinder by the hydraulic hoses.
- DO NOT Run over hydraulic cylinder or pressure hoses.
- **DO NOT** Kink the hydraulic hose.
- **DO NOT** Hit the splitter cylinder with sledge hammer to break it loose from broken rock.
- **DO NOT** Run only one cylinder at a time (minimum of 2 rock splitter cylinders)
- DO NOT Remove the cylinder handle, to allow it to slip down the hole



Application Notes

The resistance of concrete and rock to a force applied internally is only about 10% of their resistance to a force applied externally.






1. Insert splitting rods into holes.



2. Push power "ON" button. Then motor is running.



3. Turn a control lever from the middle to the left(HIGH).



4. Until hydraulic pressure gauge indicates 1,200kgf/cm², pressure is rising and falling. It takes about 45seconds ~3minutes depending on rock type. Then motor stops automatically.



5. After that, for pistons going down, turn a control lever to the right(LOW).

When pressure gauge indicate 0. Pull splitting rod out from the hole.And insert it into another hole.







7. Repeat these process for breaking rocks.



8. Set a control lever in the middle and push the stop button to stop operationg it.







Never try to locate a leak with your hands!

IMPORTANT

IF LEAKAGE OCCURS

If leakage occurs, shut down machinery immediately. **Never try to locate the leak** with your hands or any other part of the body when the hose set is pressurised. Use a suitable implement to inspect the hose for damage.



FLUID INJECTION INJURY

If a fluid injection injury occurs, it must always be treated as a **medical emergency** that requires prompt and accurate diagnosis and treatment.





"It felt like a bee-sting. Two days later my right arm was amputated"

Victim of Oil leakage